


Montage instructie
Assembly instructions
Instructions de montage
Montageanweisung
Instrucciones para el montaje
Istruzioni di montaggio

Hijsen / uitpakken / plaatsen
Lifting / unpacking / positioning
Hisser / déballer / positionner
Heben / auspacken/ aufstellen
Elevación / desembalaje / posicionamiento
Sollevamento / spacchettamento / posizionamento








Warning





Before installing, first read the installation & operating manual.





Attention

Avant installer, lisez la notice installation et d'utilisation.







C + 1100

C + 600

C

300

300

800

150


1670


720

800*


| kW | C (mm) |
|------------|--------|
| 310-285 kW | 1862 |
| 310-355 kW | 1862 |
| 310-430 kW | 1862 |
| 310-500 kW | 2172 |
| 310-575 kW | 2172 |
| 310-650 kW | 2172 |

T004016-D







13









14




15



16





T008650-C

21



© Copyright

All technical and technological information contained in these technical instructions, as well as any drawings and technical descriptions supplied, remain our property and shall not be multiplied without our prior consent in writing.

Ours is a policy of continuous development. We reserve the right to alter specifications without prior notification.

Subject to alterations.

125486-010312



125486